


1847 WALKER



1847 WALKER

#	Code	Q.ty	Description
1	A0020001	1	Frame Assembly
2	0020002	1	Hammer Assembly
3	0020003	1	Barrel 9" .44
4	A0020004	1	Wedge Assembly
5	A0020005	1	.44 Cylinder Assembly
7	A0080007	1	Hand Assembly
8	0020008	1	Backstrap
10	0080010	1	Trigger
11	0020011	1	Grip
12	0020012	1	Bolt
13	0020013	1	Loading Lever
15	0040015	1	Sight
19	0080019	1	Trigger Bolt Spring
20	0020020	1	Mainspring
24	0020024	1	Plunger
26	A0020026	1	Trigger Guard Assembly
28	0000028	1	Cylinder Lock Pin
31	0080031	2	Front Trigger Guard Screw
32	0080032	4	Rear Backstrap Screw
33	0080033	1	Wedge Screw
34	0080034	1	Plunger Screw
35	0080035	1	Trigger Bolt Spring Screw
37	0080037	1	Hammer Screw
38	0020038	2	Trigger & Bolt Screw
39	0080039	1	Loading Lever Screw
532	0020532	1	Loading Lever Latch