


1848 WHITNEYVILLE



1848 WHITNEYVILLE

#	Code	Q.ty	Description
1	A0083001	1	Frame Assembly
2	0020002	1	Hammer Assembly
3	0080003	1	Barrel 7.1/2" .44
4	A0080004	1	Wedge Assembly
5	A0080005	1	.44 Cylinder Assembly
7	A0080007	1	Hand Assembly
8	0020008	1	Backstrap
9	0080009	1	Barrel Stud
10	0080010	1	Trigger
11	0020011	1	Grip
12	0020012	1	Bolt
13	A0080013	1	Loading Lever Assembly
15	0040015	1	Sight
19	0080019	1	Trigger Bolt Spring
20	0020020	1	Mainspring
24	0080024	1	Plunger
26	A0020026	1	Trigger Guard Assembly
28	0000028	1	Cylinder Lock Pin
31	0080031	2	Front Trigger Guard Screw
32	0080032	4	Rear Backstrap Screw
33	0080033	1	Wedge Screw
34	0080034	1	Plunger Screw
35	0080035	1	Trigger Bolt Spring Screw
37	0080037	1	Hammer Screw
38	0080038	1	Trigger Screw
39	0080039	1	Loading Lever Screw
40	0080040	1	Bolt Screw